



Place this template on the underside of the chassis and line up the 4 black holes with the existing holes in your chassis. Drill a 2mm hole in the chassis through the red hole in the template and countersink to suit.